

MAINTENANCE, SAFETY, & ONE YEAR LIMITED WARRANTY INFORMATION

CARE AND MAINTENANCE

- Clean your unit with a damp cloth and wipe dry.
- Do not use any harsh cleaning chemicals on the product as the finish may be damaged.

IMPORTANT SAFETY INSTRUCTIONS

Safety is a combination of using common sense, staying alert, and knowing how your saw blade portable storage container unit works.

- Do not open more than one tray at a time.
- Always insert or remove saw blades carefully to or from a tray.
- Open each tray by pushing on the exterior pull knob with your thumb.
- Each tray fits snug; therefore, apply a little pressure with your thumb to open each tray.
- Place saw blades into an appropriate level in each tray.
- Close each tray securely using your thumb or several fingers.
- When tray is fully and safely closed, a click or snap will be heard.
- Carry the storage unit upright by the handle.
- Do not carry the storage container upside down.
- Each tray holds a maximum of 3 saw blades.
- Total of 9 circular saw blades per container/unit.
- Maximum gross weight is 20 lbs / 9.07 kg per unit.
- Do not allow the unit/container to be used as a toy.
- Use caution when using the storage container/unit near children or pets.
- Do not carry or turn the storage container upside down and then open any trays.

ONE YEAR LIMITED WARRANTY

BladeBuddy®, LLC warrants this product against defects in materials and workmanship for a period of ONE (1) YEAR from the date of retail purchase by the original end-user purchaser ("Warranty Period").

If there is a defect and a valid claim is received within the Warranty Period, the defective product can be replaced or repaired in the following ways:

(1) Contact BladeBuddy®, LLC about a repair/ replacement at BladeBuddy®, LLC's option. Proof of purchase is required at time of return. A return shipping and handling fee of \$15.00 is required to be submitted with the unit.

2) Return the product to the retailer where product was purchased for an exchange (provided that the store is a participating retailer). Returns to retailer should be

made within the time period of the retailer's return policy for exchanges only (usually 30 to 90 days after the sale). Proof of purchase may be required. Please check with the retailer for their specific return policy regarding returns that are beyond the time set for exchanges.

This warranty does not apply to defects resulting from normal wear and tear; accidents; damages sustained during shipping; alterations; unauthorized use or repair; neglect, misuse, abuse; and failure to follow instructions for care and maintenance for the product.

This warranty gives you, the original retail purchaser, specific legal rights and you may have other rights which vary from state to state or province to province.

Contact information:

BladeBuddy®, LLC

info@bladebuddy.com or www.bladebuddy.com